



For the original pattern scale, check if the box above has the right measurements!



Use this arrow to align the pattern piece in the right direction regarding your fabric's hairs, so that the hairs follow a natural direction over toothless's body!

Include a specific seam allowance of choice:

- 0.25 Inches
- 0.50 Inches
- 0.75 Inches

# WING

A more natural direction would be vertical, arrow pointing down, but since the wing is very wide, it will most likely not fit across the fabric in that direction easily. In this case, the horizontal direction above will be the most efficient way to cut your fabric.

The direction above is also a suitable one for the way the plush will be handled!

# BODY

A

Trace this shape before sewing, so you will be able to cut along it later. The wings will be sewn into the body in this place at the end!

# BODY

B

BAND B

BAND C

BAND A

BACK FINS

EAR FRONT

EAR BACK CENTER

EAR BACK LEFT

EAR BACK RIGHT

SMALL TAIL FINS

HEAD BACK

TOP SPIKE

HEAD TOP

SIDE SPIKES

HEAD SIDE

FRONT LEG

FOOT (bottom of leg)

HIP

REAR LEG

FIN A

FIN B

SKULL

HEAD SPIKES

See this

W

A

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓

↓